
START
Permit Enabling
RF Key Switch
Active
(24V)
RF Enabled
RF Enable
Permissive (C38)
Active
(24V)
HHFW Arming
Key Switch
Inactive
(24V)
RF Disable
Pushbutton
Master Disarm
Pushbutton
Inactive
(24V)
Inactive
(24V)
HHFW Disarm
Pushbutton
Satisfied
(24V)
Satisfied
(24V)
NTC in
NO ACCESS
from PSS-SIS
NSTX-U E-Stop
from PSS-SIS
HHFW Arm
Permissive (C40)