

MSE-CIF Layout on **NSTX**



MSE Issues at Low Magnetic Field

- High resolution spectrum of Doppler shifted beam emission.
- At low magnetic field overlap of Stark multiplet results in low polarization fraction with conventional filter.
- Novel birefringent filter with narrow bandpass can isolate a portion of the spectrum resulting in a much better polarization fraction(~40%).



NOVA PHOTONICS, INC.

Novel Birefringent Interference Filter Developed for NSTX



• Modular filter has a 75 mm clear aperture, wide field of view, narrow bandwidth, and is electro-optically tunable.



Birefringent Filter Development for NSTX

- Novel high throughput, narrow passband filter makes measurements with MSE at low field possible.
- Overall design has resulted in a polarization fraction greater than 40%.
- Achieved good time resolution(~5-10 ms).



NOVA PHOTONICS, INC.

Equilibrium Reconstruction with MSE



- Equilibrium reconstruction from LRDFIT and EFIT.
- Reconstruction uses Er corrected MSE data, but fit residuals are far outside the error bars, especially from EFIT.
- This has a large effect on q-profiles.





Transport Dependence on Varying Magnetic Shear

- Development of robust reversed shear startup.
- Varied Ip ramp rate, NBI timing, plasma shaping, and gas fueling.
- Plasma is L-Mode and MHD quiescent.



STX







NOVA PHOTONICS, INC.

Larger Reversed Shear Case has Better Transport

 Blue curves, with larger reversed shear region, have lower electron and ion thermal diffusivities.





Summary

 The MSE-CIF diagnostic on NSTX presently has 8 channels operational with 19 available for future upgrade. The plan is to add four additional channels for 2006 campaign.

- Novel tunable birefringent interference filter design working well. Makes MSE measurements possible at low magnetic field.
- Good progress made toward development of q-profiles with a wide range of magnetic shear for transport studies.

