


Characterization of fast ion confinement in the NSTX based on FIDA diagnostic measurements

A. Bortolon (UC Irvine)

W. W. Heidbrink (UCI), M. L. Podestà (PPPL)
and the NSTX Research Team

52nd APS-DPP Meeting
Chicago 8-12 November, 2010

College W&M
Colorado Sch Mines
Columbia U
CompX
General Atomics
INL
Johns Hopkins U
LANL
LLNL
Lodestar
MIT
Nova Photonics
New York U
Old Dominion U
ORNL
PPPL
PSI
Princeton U
Purdue U
SNL
Think Tank, Inc.
UC Davis
UC Irvine
UCLA
UCSD
U Colorado
U Illinois
U Maryland
U Rochester
U Washington
U Wisconsin




Culham Sci Ctr
U St. Andrews
York U
Chubu U
Fukui U
Hiroshima U
Hyogo U
Kyoto U
Kyushu U
Kyushu Tokai U
NIFS
Niigata U
U Tokyo
JAEA
Hebrew U
Ioffe Inst
RRC Kurchatov Inst
TRINITI
KBSI
KAIST
POSTECH
ASIPP
ENEA, Frascati
CEA, Cadarache
IPP, Jülich
IPP, Garching
ASCR, Czech Rep
U Quebec

Motivation

- ❑ Strong interest on fast ion transport: responsible for fusion yield, drive for several type of instabilities
- ❑ In NSTX Fast Ion density profile is routinely measured by FIDA diagnostic
- ❑ FIDA density profiles are observed with different degrees of peaking in different plasma conditions
- ❑ The objective of the work is to assess the fast ion density profile on an extended set of NSTX discharges
- ❑ Identify dependences on main plasma parameters, regimes with specific features in the fast ion profile

FIDA measurement concept



- ❑ Active Charge eXchange
 - Measures hot tails of Balmer alpha line
 - Large Doppler shift of recombining fast ions
 - Background subtraction is crucial
- ❑ Effective average over velocity space
 - Viewing angle
 - NBI geometry
 - Effective CX cross section
- ❑ Weighting $W_\lambda(E,p)$ function gives the sensitivity to different velocity space regions (pitch parameter $p=v_{||}/v$)




$W(E,p)$ accounts for:

1. Viewing geometry (Minimal Energy)
2. Gyro angle average
3. CX cross sections and radiative rates

FIDA spectrum
Weight function
FI distribution function

$s_f(\lambda) = \int W_\lambda(E, p) F_f(E, p) dE dp$

NSTX Vertical FIDA diagnostic



- Two systems
 - Spectroscopic (**s-FIDA**) top view
 - Filter (**f-FIDA**) bottom view


- Duplicate view to evaluate background emission
 - Faster than beam modulation
 - Toroidal symmetry hypothesis

- Vertical view
 - signal from fast ions with large perpendicular velocity
 - sensitive to high pitch angle region of velocity space
 - Important contribution from trapped fast ions

[M. Podestà RSI 79 (2008)]

FIDA density definition

- An approximate Fast Ions density may be calculated from the experimental radiance over a wavelength interval

$$I_{\Delta\lambda} = \int_{\Delta\lambda} s_f d\lambda \propto \int n_f n_b \langle \sigma v \rangle dl \approx n_f \langle \sigma v \rangle \int n_b dl$$



- The average is taken over the fast ion distribution function. To obtain n_f one should already know $F(E,p)$
- Full treatment requires accounting for $W(E,p)$ (FIDASIM code [Ref.6])

- In this work we calculate n_{FIDA} as:

$$n_{FIDA} = \frac{I_{\Delta\lambda}}{\int n_b dl} = n_f \langle \sigma_{CX} v \rangle$$


- Neutral density calculated using a pencil beam attenuation code [Ref. 7]
- Halo neutrals are not taken into account!

Example of s-FIDA spectrum



- D α cold peak recovered from neutral filter transmission function
- Impurity lines from Oxygen and Carbon (some are CX)
- Beam emission on mostly on red side
- Exploitable range on blue side 651-654 nm ($E_\lambda \sim 10-60$ keV)

NSTX parameters



Major radius 0.85 m

Aspect ratio 1.3

Elongation 2.7

Triangularity 0.8

Plasma current ~ 1 MA

Toroidal field <0.6 T

Pulse length <2 s


3 Neutral Beam sources

$P_{\text{NBI}} \leq 6 \text{ MW}$



$E_{\text{injection}} \leq 95 \text{ keV}$

$1 < v_{\text{fast}}/v_{\text{Alfven}} < 5$



Typical evolution of FIDA profiles on NSTX



- ❑ NSTX FIDA signal typically is large at the early phase of the discharge (low n_e / high NB penetration)
- ❑ Diminishes with the natural density ramp due to wall recycling
- ❑ Challenging measurement for $n_e > 6 \times 10^{19} \text{ m}^{-3}$.
- ❑ The n_{FIDA} does not respond promptly to NB steps, follows neutrons
- ❑ Different type of instabilities affect dramatically the n_{FIDA} profile (MHD, ELM, EPM, etc.)



Effect of Low Frequency MHD




- Low Freq. MHD activity strongly affects n_{FIDA}
- Often accompanied by high freq. modes
- Drop in neutron rate observed at mode onset
- n_{FIDA} profile collapse in $\sim 10 \text{ ms}$ timescale

Examples of n_{FIDA} profiles

H-mode

$P_{\text{NBI}}=6 \text{ MW}$


$n_e=4 \times 10^{19} \text{ m}^{-3}$



L-mode

$P_{\text{NBI}}=2.6 \text{ MW}$


$n_e=2 \times 10^{19} \text{ m}^{-3}$



H-mode

$P_{\text{NBI}}=6 \text{ MW}$

$n_e=1.5 \times 10^{19} \text{ m}^{-3}$




H-mode


$P_{\text{NBI}}=6 \text{ MW}$

$n_e=6 \times 10^{19} \text{ m}^{-3}$

Strong Mode Activity



Example of scaling with plasma parameters






Controlled parameters study

- ❑ Series of discharges at various couple of B_{tor} , I_p
 - ❑ $q_{95}=10$
 $n_{e,\text{lin}}=5 \times 10^{19} \text{ m}^{-2}$
 $T_e=700 \text{ eV}$
 - ❑ $t=200 \text{ ms}$ (beginning of current flat top)
-
- ❑ $n_{\text{FIDA,max}}$, dn_{FIDA}/dR increase with B_t and/or I_p
 - ❑ The onset of MHD modes and AE activity limits the comparison to specific time windows
 - ❑ Difficult to control discharge parameters, in particular n_e

Statistical approach: a database of n_{FIDA} profiles

- ❑ Database of 200 n_{FIDA} profiles from 2010 experimental run
- ❑ H-mode, $P=3-6$ MW, $B_{\text{tor}}=0.3-0.5$ T, $I_p=700-1300$ kA
- ❑ Data are averaged in time windows of 10-100 ms, with stable or slowly evolving plasma parameters (n_{FIDA} , neutron rate, mode activity,...)
- ❑ Radial profiles of n_{FIDA} , n_e , T_e , T_i ... fitted with cubic spline interpolation on major radius $R=0.95-1.5$ m
- ❑ Mode Activity described by 3 integer value flags, for low (2-20 kHz), intermediate (20-150 kHz) and high (150-2000 kHz) frequency range: values assigned manually from 0 to 3, <0 if chirping or broadband
- ❑ Investigate trends of n_{FIDA} maximum, peaking and peak location



Parameter space coverage



- Magnetic configuration (from EFIT)
- T_e, n_e (from Thomson scattering)
- T_i, v_{tor} (from Charge Exchange)
- Neutron Rate
- ...


Maximal value of n_{FIDA}

- The dependency of the peak value of n_{FIDA} on B_{tor} , n_e , q_{95} , P_{NBI} has been considered for the entire set of samples
- No clear trend is apparent



FIDA density peaking: B_{tor} dependence


- ❑ Peaking parameter defined as $P(x) = x_{\text{max}} / \langle x \rangle$, (maximum value, normalized by the linear average in the region $R=1.05-1.40$ m)
- ❑ $P(n_{\text{FIDA}})$ spans values from 1.5-3.5



n_{FIDA} peaking
decreases with B_{tor}

No clear correlation
with I_p or q_{95}

FIDA density peaking: n_e dependence




Correlation suggested with electron density n_e


No apparent correlation with I_p or q_{95}

May be related to incorrect estimate of neutral density (e.g. halo neutrals are not included)

Effect of strong Low Frequency Mode Activity




- ❑ Select two classes of profiles characterized by different degrees of mode activity (freq. < 20 kHz)
- ❑ Restricting to high FIDA signal profiles to improve quality (30% of total samples)



Reduced FIDA density in presence of mode activity


No clear distinction on n_{FIDA} peaking dependence on B_{tor}

Radial location of FIDA density peak



- The peak displacement is defined as:

$$\Delta R_{max} = R(n_{FIDA,max}) - R_{axis}$$
- Selection of Low Mode Activity samples
- Correlation emerges with β_p
- ΔR_{max} decreases with β_p



- The displacement (with large scatter) also correlates with R_{axis}
- $\Delta R \sim -1.0 R_{axis}$
- n_{FIDA} peak close to $R=1.05m$
- Related to the Fast Ion source location

Conclusions

- ❑ A database of FIDA density profiles has been built to study the dependences on plasma parameters
- ❑ Peaked n_{FIDA} is generally observed, with peaking factor of 2-3
- ❑ Peaking n_{FIDA} scales with n_e and B_{tor}
- ❑ Different degrees of peaking are observed in combination with low frequency MHD or Alfvénic modes
- ❑ Off axis n_{FIDA} peak tends to sit close to $R=1.05$ m

- ❑ The n_{FIDA} density definition depends on FI distribution function: variation in velocity space can affect n_{FIDA}
- ❑ Halo neutrals are not accounted by the beam deposition code used
- ❑ The FI population depends strongly on Mode Activity and its history: difficult to obtain a coherent set of profiles

- ❑ Need to increase the number of data samples to allow for reliable analysis on restricted sets

Outlook

- ❑ Use of **FIDASIM synthetic diagnostic** to compare the experimental profiles and spectra with theoretical models of the distribution function (specific cases) [Y.Luo, [Improvements to the Fast-ion \$D_\alpha\$ \(FIDA\) Simulation Code \(BP9-PS1\)](#)]
- ❑ FIDASIM may be used to predict the dependency on B_{tor} and n_e on the assumption of a given FI distribution function
- ❑ Improve the neutral density calculation including halo neutrals (FIDASIM)

- ❑ Use of the data from the **new tangential FIDA** to identify velocity space variation of the FI distribution function

References

1. [M. Podestà RSI 79 \(2008\)](#)
2. [W. W. Heidbrink RSI 79 \(2008\)](#)
3. [W. W. Heidbrink PPCF 49 \(2007\)](#)
4. [W. W. Heidbrink RSI 81 \(2010\)](#)
5. [A. Bortolon RSI 81 \(2010\)](#)
6. [W.W. Heidbrink CCP 8 \(2010\) submitted](#)
7. [R.E. Bell RSI 77 \(2006\)](#)
8. [M. Podestà PoP 16 \(2009\)](#)
9. [E. D. Fredrickson PoP \(2006\)](#)


Coming soon: A Tangential FIDA diagnostic for NSTX

- ❑ In NSTX, Fast-Ions are generated by the heating Neutral Beams (co current tangential injection)
- ❑ The distribution function is populated in the region of high parallel velocity $\Rightarrow p > +0.5$
- ❑ Installation of a tangential FIDA diagnostic is about to begin to study the high parallel velocity region of the phase space


- ❑ Key points:
 - Maximize view alignment with local magnetic field B
 - **Spectroscopic** and **Filter** instruments scheme
 - Paired active and background views scheme

- ❑ Sampling the (p, E) space where the distribution function is more populated \Rightarrow enhanced FIDA spectrum source
- ❑ Contribution from Fast Ions with large parallel velocity \Rightarrow spectrum extends to higher energies


Tangential FIDA diagnostic views



Response function of t-FIDA



- $W_\lambda(E, p)$ evaluated at
 - $R=1.2$ m,
 - $E_\lambda=35$ keV (652.1 nm)
- Tangential view is sensitive to $p>0.8$
- Contribution from small region of phase space



- Enhanced energy resolution
- Enhanced source of FIDA signal

***Complementary sampling
of velocity space***