



Motivation

- Current solid plasma facing components (PFCs) present issues such as neutron damage/activation, thermal fatigue and erosion.
- Liquid metal surfaces avoid these issues as they are self healing.
- Lithium has a high chemical affinity for hydrogen, which has resulted in reduced recycling of D and enhanced plasma performance on TFTR, NSTX and other tokamaks.
- Tokamaks do not have ultrahigh vacuum (UHV) conditions; lithium will react with residual gases creating oxides and other compounds quickly after deposition.
- It is important to characterize the chemical composition of the lithium surface to provide a design basis for PFCs.
- Mo(110) single crystal is used for comparison with TZM (machineable Ti-Zr-Mo alloy) to elucidate the effect of grain boundaries and alloying components of TZM.



Study of Mo as a substrate material is motivated by the Liquid Lithium Divertor (LLD) installed in NSTX in 2010 and the move to all-metal PFC with TZM tiles.

Surface Science at PPPL

Facilities:


- We use atomic-level diagnostics to investigate the surface processes and chemical reactions that occur at the plasma-surface interface.

Approach:

- Probe surface composition, chemistry, and morphology while independently controlling the vacuum conditions, surface temperature, and incident neutral/ion flux to simulate the environment in a fusion device.

ALISS chamber:


- The ALISS chamber is an ultrahigh vacuum (UHV) surface analysis chamber with a range of diagnostics and surface preparation techniques. Main capabilities and instrumentation include:



- X-ray photoelectron spectroscopy (XPS)
- Auger electron spectroscopy (AES)
- Temperature Programmed Desorption (TPD)
- Low energy ion scattering (LEIS)
- Low energy electron diffraction (LEED)
- Alkali ion scattering spectroscopy (ALISS)


- Samples mounted in vacuum chamber operating at 10^{-10} Torr with LN₂ cooling and e-beam/resistive heating capable of achieving a wide temperature range (<200 K to >1600 K)
- Ultrathin Li layers, <10 monolayers (ML) deposited with sub-monolayer control
- Mass analyzed, differentially pumped ion source produces a clean consistent ion source for hydrogen retention studies

Li Desorption from TZM and Mo(110)



Skinner et al. J. Nucl. Mater. 438 (2013) S647


- TPD spectra show Li (7 amu) desorption from films of increasing amounts on TZM and Mo(110)
- Peak at 560 K is attributed to multilayer Li desorption while 750 K peak is attributed to Li monolayer
- Li TPD are similar for TZM and Mo(110); Li desorption shoulder is larger and extends to slightly higher temperature on TZM



Mo(110) is resistively heated in UHV.


Oxidation of Li Films on Mo(110)

- Li films of varying thickness were exposed to 10 L (Langmuir: 1 s at 10^{-6} torr) O₂ to observe oxide formation as a function of Li film thickness
- 5 peaks were observed: 800 (only for 3 ML Li deposition), 950 1050, 1200 and 1350 K
- Each peak represents Li on the surface with a different thermal stability; this can be caused by changes in bonding (e.g. Li-Mo vs Li-Li) or compound formation (e.g. Li, Li₂O)




Oxidation of Li monolayer on Mo(110)

- Li oxidation was measured on 1 ML films
- At 1 L dose, TPD curve shifted to higher temperatures with new peaks: 950, 1050, 1200 and 1350 K
- 950 K peak decreased, 1200 K peak increased with increasing O₂ dose




Characterizing Different Li Compounds

- TPD spectra show Li desorption from 3 ML Li films on Mo(110) exposed to a 5 L O₂ dose
- Bottom curves show TPD of un-oxidized Li and no Li dose for comparison
- Heating (annealing) films to near a peak temperature removes that peak allowing for study of individual peaks
- TPD curves showing annealing of 3 ML oxidized Li film at 800, 950, 1050 and 1200 K are shown




AES of Li films After Annealing at Various Temperatures




- AES was performed after deposition and annealing to measure changes to the surface composition
- AES of clean lithium film shows no oxygen (510 eV) or carbon (272 eV) on the surface. Mo (186 & 211 eV) and Li (47 eV) are both prominent
- After oxidation, Li peak shifts from 47 eV to 40 eV.
- Comparing peak heights of AES spectra provides elemental composition at surfaces for the TPD peaks observed
- Further study planned using XPS and vibrational spectroscopy to identify Li compounds desorbed at each TPD peak

Oxidation of Li on Mo(110) with Surface C

- TPD shows Li desorption from an oxidized Li monolayer film on clean Mo(110) and Mo(110) with surface C exposed to a 10 L O₂ dose.
- Li desorption from Mo(110) with surface C has larger peak at 1050 K and reduced peak at 1200 K
- Surface carbon does not significantly affect un-oxidized Li TPD (TPD not shown)
- How does C on surface affect Li oxidation? Plans to study chemistry of oxidized Li films on C coated Mo(110) with XPS.



AES of Li films on Clean and C Contaminated Mo(110)



Summary

- Li desorption from Mo(110) is similar to that observed for Li on TZM; differences in high temperature shoulder could be due to grain boundaries in TZM.
- Multiple TPD peaks are formed by oxidation of Li films on Mo(110). Peaks represent thermal stability of different Li-oxides
- Individual Li TPD peaks analyzed by annealing sample to remove Li compounds desorbing at lower temperature peaks.
- Surface C does not affect thermal stability of Li film on Mo(110)
- Surface C has significant effect on the interactions of Li film with oxygen

Near term plans:

- Expand study of composition of oxidized and carbon contaminated Li films on Mo(110) with XPS and vibrational spectroscopy
- Study effect of hydrogen ion implantation on pure and contaminated Li films.

Acknowledgements

The authors would like to thank Doug Labrie, Gus Smalley, Tom Provost, and Tom Holoman for their technical assistance. We acknowledge support by the Office of Fusion Energy Science, Office of Science, U.S. Department of Energy grant no.

DE-SC0008598