


Comparison between Simulation and NSTX Measurements using Synthetic Reflectometry

Lei Shi

*CS. Chang, A. Diallo, G. J. Kramer, S. Ku, W. M. Tang,
E. J. Valeo
and the NSTX Research Team*

**56th APS-DPP Annual Meeting
New Orleans, LA
Oct. 28, 2014**

*Coll of Wm & Mary
Columbia U
CompX
General Atomics
FIU
INL
Johns Hopkins U
LANL
LLNL
Lodestar
MIT
Lehigh U
Nova Photonics
ORNL
PPPL
Princeton U
Purdue U
SNL
Think Tank, Inc.
UC Davis
UC Irvine
UCLA
UCSD
U Colorado
U Illinois
U Maryland
U Rochester
U Tennessee
U Tulsa
U Washington
U Wisconsin
X Science LLC*



*Culham Sci Ctr
York U
Chubu U
Fukui U
Hiroshima U
Hyogo U
Kyoto U
Kyushu U
Kyushu Tokai U
NIFS
Niigata U
U Tokyo
JAEA
Inst for Nucl Res, Kiev
Ioffe Inst
TRINITI
Chonbuk Natl U
NFRI
KAIST
POSTECH
Seoul Natl U
ASIPP
CIEMAT
FOM Inst DIFFER
ENEA, Frascati
CEA, Cadarache
IPP, Jülich
IPP, Garching
ASCR, Czech Rep*

Synthetic reflectometry has been applied to plasma simulation code to compare with experimental results

- A synthetic reflectometry code (FWR2D/3D ^[1]) has been interfaced to a gyro-kinetic PIC code (XGC-1^[2]).
 - XGC-1 is a first principle code, self-consistently calculates fluctuations
 - Use measured equilibrium profiles as input, no free parameters
- The result has been compared with measurements from the edge in NSTX.
- The comparison shows a fair agreement in both local fluctuation levels and radial correlation lengths.

[1] E. J. Valeo et al Plasma Phys. Control. Fusion 44 (2002) L1–L10

[2] S. Ku et al Nucl. Fusion 49 (2009) 115021



Density fluctuations from XGC-1 are used in reflectometer simulations with the FWR codes

- XGC-1

- Self consistent, global simulation of fluctuations
- Full-f, kinetic electrons, nonlinear

- FWR2D/3D

- Full wave reflectometer codes in 2D/3D Cartesian geometry
- Calculates reflection patterns in presence of density fluctuations




Mapping from density fluctuation to reflected electric field is needed to compare simulation with experiment


- XGC-1 gives time series of density fluctuations: $\frac{\tilde{n}}{n}$
- In experiment we measure a time series of the reflected electric field at the receiver: \tilde{E}
- The map from density fluctuations $\frac{\tilde{n}}{n}$ to the measured electric field \tilde{E} is non-linear!
- Synthetic reflectometer code is able to take the simulated density fluctuations from XGC-1 and map them to electric field fluctuation.

FWR2D/3D is used to map XGC1 simulated density fluctuations to reflected E field

$\tilde{n}_e(t)$ from XGC1 near the reflection



\tilde{E}_{refl} from FWR2D for the corresponding channel



Now, we need to compare synthetic E field and measured E field.

Statistical methods are used to compare the synthetic signal with the observed signal in the experiment

- Coherent Signal $|g|$
 - Single channel analysis
 - A measure of fluctuation level
 - $|g| \rightarrow 0$: Large fluctuations
 - $|g| \rightarrow 1$: Small fluctuations



$$g \equiv \frac{\langle \tilde{E} \rangle}{\sqrt{\langle |\tilde{E}|^2 \rangle}}$$

- Cross-correlation $|\gamma|$
 - Correlation between two channels
 - \leftrightarrow correlation between two radial locations

$$\gamma_{ij} \equiv \frac{\langle \tilde{E}_i^* \tilde{E}_j \rangle}{\sqrt{\langle |\tilde{E}_i|^2 \rangle \langle |\tilde{E}_j|^2 \rangle}}$$

$|\gamma| \rightarrow 1$: Highly correlated channels, fluctuation spatial scale might be larger than the distance

Coherent signal and cross correlation show fair agreement between self-consistent simulation and experiment



XGC-1 simulation can be further improved

- Collisional effects
 - More damping → Lower fluctuation level
 - May lead to better agreement in coherent signal
- Neutral source from the wall
 - Neutrals play a significant role near the edge
 - May change the spatial structure
- External heating and particle injection
 - Sustain the nonlinearly saturated state for longer, provide a larger statistical ensemble, lower the statistical uncertainties.
- Electro-magnetic modes

XGC1 calculated fluctuation level and radial correlation length are both in fair agreement with experiment

- Synthetic reflectometry is used to compare plasma simulation result with experiment.
- For the NSTX case we studied, XGC-1 result is in fair agreement with experimental observations.
 - Reflected signal's radial correlation length agrees within roughly a factor of 2
 - Implied fluctuation level also agrees fairly well.
- Future work:
 - More comprehensive XGC-1 run (described in the previous slide)
 - Interface the reflectometry code to other simulation codes (GTS, GTC, M3D-C1, GENE, GYRO, etc.)