

**Princeton Plasma Physics Laboratory  
NSTX Experimental Proposal**

**Title: Liquid Lithium Divertor recycling and pumping studies**

**OP-XP-1001**

Revision:

Effective Date:  
*(Approval date unless otherwise stipulated)*  
Expiration Date:  
*(2 yrs. unless otherwise stipulated)*

**PROPOSAL APPROVALS**

**Responsible Author: V. A. Soukhanovskii**

Date

**ATI – ET Group Leader: C. H. Skinner**

Date

**RLM - Run Coordinator:**

Date

**Responsible Division: Experimental Research Operations**

**RESTRICTIONS or MINOR MODIFICATIONS**  
(Approved by Experimental Research Operations)

# NSTX EXPERIMENTAL PROPOSAL

TITLE: **LLD recycling and pumping studies**  
AUTHORS: **V. A. Soukhanovskii, M. Jaworski, J. Kallman, H. W. Kugel, R. Maingi, R. Raman, and NSTX Team**

No. **OP-XP-1001**  
DATE:

---

## 1. Overview of planned experiment

This XP is a part of a series of experiments that aim at characterizing the liquid lithium divertor (LLD) performance. In this experiment, pumping and recycling characteristics of the LLD and the surrounding lower divertor surfaces will be studied as functions of the steady-state core ion density, divertor density, and LLD temperature regime. Additionally, particle containment times ( $\tau_p^*$ ) characterizing pump-out of the edge and SOL density will be measured or inferred using measurements-based particle balance models.

## 2. Theoretical/ empirical justification

Laboratory measurements (e.g., R. Doerner et al., Nucl. Fusion 42, 1318 (2002)) showed that liquid lithium retention of incident ions is a function of both liquid lithium temperature and ion fluence. This experiment aims at measuring the LLD pumping (i.e. dynamic retention) and recycling processes under a variety of temperature and incident ion flux conditions. A prerequisite to this experiment is XP 1000 by H. W. Kugel et al. The latter XP is expected to address the following points:

- Demonstration of reduced ion density / inventory with “warm” LLD ( $T=215-240$  C) (i.e., pumping vs distance to strike point)
- Operational scenario for proper LLD thermal regime (i.e., temperature vs distance to strike point, NBI power)
- Impurity influx and core content with cold and warm LLD
- LITER evaporation requirements such as evaporation rate and evaporation frequency

## 3. Experimental run plan

### 1. Steady-state ion density scan and Density pump-out ( $\tau_p^*$ ) measurements

#### 1.1. Establish a long-pulse H-mode discharge with SGI fueling and “cold” LLD (2-3 shots)

- Use SGI scenarios from shots 134134, 134136, 134991 as guidance. If shots do not go through, use 200-400 Torr in high field side injector. SGI regime:  $R=158$  cm, 5000 Torr, 10 ms pulses.
- Use highest  $P_{NBI}$  possible while avoiding  $\beta$ -limiting instabilities (from XP 1000, e.g., 3 MW or 5 MW)
- Use shaping similar to the best discharges with LLD pumping from XP 1000, e.g. high-triangularity with  $R_{OSP}=0.45$  m, or medium triangularity with  $R_{OSP}=0.63$  m. Use isoflux control for GAPOUT=10 cm
- Use best LITER scenario established in XP 1000

**OP-XP-**

- 1.2. Obtain several reference discharges with cold LLD and several core ion density (ion inventory) values by adding or removing SGI pulses in the fueling scenario (up to 10 shots)
  - Expected range of steady-state ion densities  $1-6 \times 10^{19} \text{ m}^{-3}$
  - Obtain core, edge, SOL, and divertor ion and electron densities from multiple diagnostics for particle balance analysis
  - Add 1-3 SGI pulses after 0.4-0.5 s for “pump-out” characterization
- 1.3. Repeat best discharges from 1.2 with “warm” LLD to document density behavior (up to 10-15 shots)
  - Use LDGIS gas injection in flat-top phase in 1-3 shots to document divertor density pumpout. LDGIS setup: plenum pressure 200-400 Torr.
- 2 LLD pumping as function of LLD temperature (up to 15 shots). If technically possible and administratively allowed, characterize pumping and recycling with LLD at higher temperature.
  - Desirable range of LLD temperatures 200-320 C
  - Repeat best shots from 1.2 and 1.3 with LLD at higher temperature
  - If LLD higher temperature is obtained as a result of plasma heating during a discharge, assure that best SGI pulse scenarios were used for pumpout characterization (parts
  - Optional, time-permitting – repeat 1.3.1 for divertor pumpout characterization

#### **4. Required machine, NBI, RF, CHI and diagnostic capabilities**

Prerequisite: XP 1000 as described in Section 2.

#### **5. Planned analysis**

EFIT, TRANSP, particle balance equations, UEDGE, SOLPS, DEGAS 2

#### **6. Planned publication of results**

Results will be presented in upcoming fusion meetings and major refereed publications.

# PHYSICS OPERATIONS REQUEST

TITLE: **LLD recycling and pumping studies**  
AUTHORS: **V. A. Soukhanovskii et al.**

No. **OP-XP-1001**  
DATE:

**Brief description of the most important operational plasma conditions required:**

**Section 1.1**

**Previous shot(s) which can be repeated:**

**Previous shot(s) which can be modified:** 134134, 134136, 134991 and shots from XP 1000

**Machine conditions** (*specify ranges as appropriate, strike out inapplicable cases*)

$I_{TF}$  (kA): Flattop start/stop (s):

$I_p$  (MA): Flattop start/stop (s):

Configuration: **Limiters** / DN / LSN / USN

Equilibrium Control: **Outer gap** / **Isoflux** (rtEFIT) / **Strike-point control** (rtEFIT)

Outer gap (m): Inner gap (m): Z position (m):

Elongation: Triangularity (U/L): OSP radius (m):

Gas Species: Injector(s):

**NBI Species:** **D** Voltage (kV) **A:** **B:** **C:** Duration (s):

**ICRF Power** (MW): Phase between straps (°): Duration (s):

**CHI:** **Off / On** Bank capacitance (mF):

**LITERs:** **Off / On** Total deposition rate (mg/min):

**LLD:** Temperature (°C):

**EFC coils:** **Off/On** Configuration: **Odd / Even / Other**

**OP-XP-**

## DIAGNOSTIC CHECKLIST

TITLE: **LLD recycling and pumping studies**

No. **OP-XP-1001**

AUTHORS: **V. A> soukhanovskii et al.**

DATE:

*Note special diagnostic requirements in Sec. 4*

*Note special diagnostic requirements in Sec. 4*

Diagnostic	Need	Want
Beam Emission Spectroscopy		
Bolometer – divertor		√
Bolometer – midplane array		√
CHERS – poloidal		√
CHERS – toroidal	√	
Dust detector		
Edge deposition monitors		
Edge neutral density diag.		√
Edge pressure gauges	√	
Edge rotation diagnostic		√
Fast cameras – divertor/LLD	√	
Fast ion D <sub>α</sub> - FIDA		
Fast lost ion probes - IFLIP		
Fast lost ion probes - SFLIP		
Filterscopes	√	
FIRETIP		√
Gas puff imaging – divertor		
Gas puff imaging – midplane		
H <sub>α</sub> camera - 1D	√	
High-k scattering		
Infrared cameras	√	
Interferometer - 1 mm		
Langmuir probes – divertor	√	
Langmuir probes – LLD	√	
Langmuir probes – bias tile		√
Langmuir probes – RF ant.		√
Magnetics – B coils	√	
Magnetics – Diamagnetism		
Magnetics – Flux loops	√	
Magnetics – Locked modes		
Magnetics – Rogowski coils	√	
Magnetics – Halo currents		
Magnetics – RWM sensors		
Mirnov coils – high f.		
Mirnov coils – poloidal array		
Mirnov coils – toroidal array		
Mirnov coils – 3-axis proto.		

Diagnostic	Need	Want
MSE		
NPA – EllB scanning		
NPA – solid state		
Neutron detectors		
Plasma TV	√	
Reflectometer – 65GHz		
Reflectometer – correlation		
Reflectometer – FM/CW		
Reflectometer – fixed f		
Reflectometer – SOL		√
RF edge probes		
Spectrometer – divertor		√
Spectrometer – SPRED		√
Spectrometer – VIPS		√
Spectrometer – LOWEUS		√
Spectrometer – XEUS		√
SWIFT – 2D flow		
Thomson scattering	√	
Ultrasoft X-ray – pol. arrays		
Ultrasoft X-rays – bicolor		
Ultrasoft X-rays – TG spectr.		√
Visible bremsstrahlung det.		√
X-ray crystal spectrom. - H		
X-ray crystal spectrom. - V		
X-ray tang. pinhole camera		